

6500 Dobry Dr. Sterling Heights, MI 48314
Web Site: www.backflowtestkits.com

Phone 586-254-6500 Fax 586-254-6905
Email: www.sales@midwestinstrument.com

Professional Test Cock Cleaning Tool



Part No. 110694 Test Cock Cleaning Tool

- Install the Test Clean into the plugged test cock
- Open test cock and depress plunger to clear the obstruction
- Back out plunger and flush debris into a bucket or floor drain
- Remove the Test Clean and proceed with testing

INSTRUMENTS • CONTROLS • VALVES

ARCO
Engineering, Inc.
SINCE 1954
www.arcoengineering.com

3317 Gilmore Industrial Blvd.
Louisville, KY 40213

Ph: (502) 966-3134
Fx: (502) 966-3135

Part No. 110705
Quick Connect Test Cock Adapters
(90° Swivel Fittings)

Rotate 360° after installation • Ideal for tight spaces
(Set of 3)

Includes:

- (3) 1/4" NPT Quick Connect x 1/4" Flare
- 90° Swivel Fittings
- Spare O'rings



Part No. 110706
90° Swivel Quick Connect Test Cock Adapter Kit
(Set of 9)

Set includes all fittings required to test any size Backflow device. 90° Elbow Swivel Fittings - Rotate 360° after installation. Ideal for tight spaces.

Includes:

- (3) pieces 90° Swivel 1/4" NPT x 1/4" Flare Quick Connect Fittings
- (3) pieces 1/2" NPT x 1/4" FNPT Quick Connect Fittings
- (3) pieces 3/4" NPT x 1/4" FNPT Quick Connect Fittings

Includes: 3 spare O-rings per size Packaged in a convenient plastic storage tube.



Quick Connect Test Cock Adapters

Designed for hand tight connection of Differential Pressure Test Gauges to Backflow Prevention Assemblies.

No Wrenches or Teflon Tape Required.

Part No. 110631

1/4" NPT Quick Connect x 1/4" Flare
3 Spare O-Rings

Part No. 110703

1/2" NPT Quick Connect x 1/4" Flare
3 Spare O-Rings

Part No. 110704

3/4" NPT Quick Connect x 1/4" Flare
3 Spare O-Rings

Part No. 110617 Quick Connect Test Cock Adapter Kit

Designed for hand tight connection of Differential Pressure Test Gauges to Backflow Prevention Assemblies. Set includes all fittings required to test any size Backflow device.

No Wrenches or Teflon Tape Required.

- (3) 1/4" NPT X 1/4" Flare
- (3) 1/2" NPT X 1/4" FNPT
- (3) 3/4" NPT X 1/4" FNPT

Includes 3 spare O-rings per size Packaged in a convenient plastic storage tube.





Part No. 109425
Standard NPT Adapter Fitting Kit

Fittings to connect Differential Pressure Test Gauges to Backflow Prevention Assemblies

Set includes:

- (3) 1/8" NPT X 1/4" Flare
- (3) 1/4" NPT X 1/4" Flare
- (3) 1/2" NPT X 1/4" FNPT
- (3) 3/4" NPT X 1/4" FNPT

2 Foot long chain to hang a test kit from the valve.



Part No. 830-0003
(For USC Test Procedures)

Vertical Tube Kit

Includes:

- 15" X 1/2" Dia. Tube/Test Cock Adapter Assembly*
- 15" X 1/2" Dia. Extension Tube Assembly*
- 15" Is Assembled Length.




Part No. 830-0001
(For USC Test Procedures)
Bleed-Off Valve Assembly
(soft seated needle valve)

Part No. 110645

Model 830 - Five Foot Replacement Hose Assembly Kit.

Set of 3 - (Red, Green, Black)

1/4"-90° Hex Flare and 1/4" Straight Quick Coupler. Field serviceable filter housing and filters included.



Part No. 110646

Model 844/845 - Five Foot Replacement Hose Assembly Kit.

Set of 3 - (Red, Green, Black)

1/4" Straight Quick Coupler - Both Ends. Field serviceable filter housing and filters included.



Part No. 98008

Replacement Filter Element Kit
Set of 6



Part No. 109445

Filter Assembly Adapter Kit
Set of 3 -12" hoses.

For Test Kit Hoses that do
not have filters.

1/4" Quick Coupler
x 1/4" Flare Connection.

Field serviceable filter housing and
filters included.



Part No. 110405

Test Kit Carrying Case with Foam